

Rietschle-Thomas Linear Diaphragm Blower LP Range Spare Parts Listing

| LP-80HN, LP-80-100-120H | |
|-------------------------|----------------|
| Major Repair Kit | MRK80100120H |
| Chamber Block Set | 801LP100CPB31D |
| Rod Assembly - 80HN | 877LP80FBAY |
| Rod Assembly - 80H | 877LP80AY |
| Rod Assembly - 100H | 877LP100FGAY |
| Rod Assembly - 120H | 877LP120AY |
| Air Cleaner Filter | 898LP100H0 |
| Air Cleaner Gasket | 870LP100HF0 |
| Tank Gasket | 870LP100T0 |
| L-Tube | 851LP100H00 |
| Protective Switch | 812LP80HAY |
| Pipe Connector | 872LP30AYA3 |
| Pipe Connector 90° | 851EOVW1723 |
| LP-80A | |
| Diaphragm Block | 878LP70PB36 |

| LP-70H, LP-120A | |
|--------------------|-------------|
| Major Repair Kit | MRK70H |
| Diaphragm Block | 878LP70PB1 |
| Casing Block | 801LP60CB2 |
| Rod Assembly | 877LP70AY |
| L-Tube | 851LP30LAY1 |
| Protective Switch | 871LP80AY |
| LP-60A, LP-100A | |
| Major Repair Kit | MRKLP60A |
| Chamber Block Set | 801LP60CPB1 |
| Rod Assembly | 877LP60AY |
| L-Tube | 851LP30LAY2 |
| LP-80A, 100A, 120A | |
| Air Cleaner Filter | 898LP8000 |
| Air Cleaner Gasket | 870LP8000 |
| Tank Gasket | 870LP80T0 |

| LP-60A, 60H, 70H | |
|--------------------|--------------|
| Air Cleaner Filter | 898LP3000 |
| Air Cleaner Gasket | 870LP30F0 |
| Tank Gasket | 870LP30T0 |
| LP-150-200H | |
| Major Repair Kit | MRK150200H |
| Chamber Block Set | 801LP150CP0 |
| Valve | 876LPF0V1 |
| Valve Gasket | 870LP150H0 |
| Rod Assembly | 877LP200FGAY |
| Air Cleaner Filter | 898LP150H0 |
| Air Cleaner Gasket | 870LP150HF0 |
| Tank Gasket | 870LP150HT0 |
| L-Tube | 851LP150H00 |
| Protective Switch | 812LP150HAY |

If you have any questions regarding blower parts, please contact W.E.S.
PH. 07 3216 5266 EM wes@pacific.net.au WEB www.wastewaterequipment.com.au